

TROLLEY MADDISON 4-LEG



TROL/MV4



Stacks 10 chairs high.

Features:

- Easy maneuverability.
- Red powder coat finish.
- Strong welded steel frame.
- Suitable for MV, BMV and adjustable 4-leg range.

Warranty:

- 3 year.

Weight:

- 150kg load rating.

Dimensions:

Overall Stacking Platform

W	D	H
600	1060	1300
385	425	355



Ergonomic Handle for single handed control.



Heavy duty tubeless wheels (flat free).



Non-marking rubber swivel brake wheel.



TROLLEY MADDISON 4-LEG



Step 1

- Place the trolley in an upright position.
- In this position stack the chairs to a maximum of 5-high.

or

Chairs can be stacked to a maximum of 5-high prior



Step 2

- Place your foot on the axel and firmly hold the chair backs and ergonomic handle.
- Using the ergonomic handle, gently pull backwards lowering the trolley to rest on the swivel brake wheel.



Step 3

- Firmly push down the wheel brake with your foot locking the trolley into place to prevent movement.



Step 4

- Load the balance of the remaining chairs as shown to a maximum of 10-high.
- Disengage the brake for easy maneuverability to their destination using the ergonomic handle.